

CAUTION – RISK OF SHOCK –

Disconnect Power at the main circuit breaker panel or main fuse box before starting and during the installation.

INSTRUCTIONS

For Assembling and Installing Fixtures in Canada
Pour L'assemblage et L'installation Au Canada

- 1) Pass fixture wire from the stem through the hole in the bottom of the canopy. Pass the top of the stem through the hole.
- 2) Slip lockwasher onto the threaded end of the stem protruding from the canopy. Thread nut onto end of stem. Tighten nut to secure fixture to canopy.
- 3) Insert recommended bulbs (Not supplied)
- 4) Attach each bead strand onto holes located on bottom side of center ring. (you may need to pinch with needle nose pliers to secure hook). Attach other end onto holes of top side of center ring.
- 5) Attach other end of beads onto holes of top side of bottom trim.
- 6) Find the appropriate threaded holes on mounting strap. Assemble mounting screws into threaded holes.
- 7) Attach mounting strap to outlet box. Mounting strap can be adjusted to suit position of fixture.
- 8) Make wire connections. Reference chart below for correct connections and wire accordingly.

- 9) Push fixture to ceiling, carefully passing mounting screws through holes in canopy.
- 10) Thread lock-up knobs onto ends of mounting screws. Tighten lock-up knobs to secure fixture to ceiling.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)

